

How to Read Your Meter's LCD Screen

Display values for the EKM-Omnimeter I v.3:



Total kWh (Forward kWh + Reverse kWh)



Reverse kWh



Voltage Line 1



Voltage Line 2



Voltage Line 3



Current (Amps) Line 1



Current (Amps) Line 2



Current (Amps) Line 3



Power (Watts) Line 1



Power (Watts) Line 2



Power (Watts) Line 3



Total Power (Watts)



Power Factor Line 1



Power Factor Line 2



Power Factor Line 3



Display values for v.2 Smart Meters:



Total kWh



Reverse kWh




Voltage



Current (Amps)



Power (Watts)



Power Factor Line 1



Power Factor Line 2

Note: 120V Meters do not have a reading for L2 because they only read one line.

Pulse counts for 25EDSP-N:



Pulse Count 1



Pulse Count 2



Pulse Count 3

